

Work Order ID 137864

Tuesday, October 13, 2015 3:36:14 PM

137864

Ship out

Page 1

Item ID: D350-689-021 Accept ***N900040100*** Setup Start ***NS1***
 Revision ID: Stop ***NS2***
 Item Name: Dual High-Back Seat Installation - Energy Attenuating Seat Compatible
 Start Date: 10/13/2015 Start Qty: 1.00 ***1*** Cust Item ID:
 Required Date: 10/29/2015 Req'd Qty: 1.00 ***1*** Customer:
 Reference:

Approvals: Process Plan: mc Date: 15-10-13 Tooling: _____ Date: _____ Run Start ***NR1***
 QC: _____ Date: _____ SPC (Y/N): _____ Date: _____ Stop ***NR2***

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
Draw Nbr	Revision Nbr								
IIN-D350-689	C								
100	Document Control	0.00							
100	DOCUMENT CONTROL								
DC	Memo	0.00							
Doc.Control -USB or Paperwork	Photocopy bluefile and create labels per PPP D350-689-021 CHG006								
110	Pick Kit	0.00							
110									
Packaging	Memo	0.00							
Packaging									
120	QC4- 100% Inspect kits for completeness	0.00							
120									
QC	Memo	0.00							
Quality Control									

IX **DAS 28 9-89** **DEC 10 2015**

IX **DAS 27 9-89** **NOV 20 2015**

IX **DAS 28 9-89** **DEC 10 2015**

DQA: _____ Date: _____



WORK ORDER NON-CONFORMANCE / UPDATE

QA Closed: _____ Date: _____

Work Order update only ☐

Work Order: _____ Part No. _____ NCR No. _____		DISPOSITION Rework ☐ Scrap ☐ Use-as-is ☐ Suspected Unapproved ☐ Skid-tube ☐ Machining ☐ Thermoforming ☐ Large Fab ☐ Cross tube ☐ Small Fab ☐ Finishing ☐ Composite ☐ Water Jet ☐ Prod. Eng. Coord. ☐ Rec/Store/Packaging ☐ Supplier ☐ Engineering ☐ Quality ☐ Other ☐		AGAINST DEPARTMENT/PROCESS																																																													
Date :		Step #:		QTY Effective :			MRB (QSI042) Approval																																																										
Description Work Order Deviation				Disposition				Completed By																																																									
								Lead hand / Supervisor Approval Verification																																																									
								QC / QA Coordinator Approval																																																									
Root Cause		FAULT CATEGORY																																																															
Environment ☐	No Re-verification ☐	Pressure/Forced ☐	Temperature/Cure ☐	Power Loss/Surge ☐	Positioned Wrong ☐	Design ☐	Operator ☐	Bending ☐	Set-up ☐	Folio/Program ☐	Outside Dimensions ☐	Doc/Data ☐	Offset/Setup ☐	Centre Not Concentric ☐	BOM/Route ☐	Grain ☐	Over/Under tolerance ☐	Equip/Tooling ☐	Supplier ☐	Cracks ☐	Broken/Damage/Defect ☐	Weld ☐	Part Incorrect ☐	Handling/Pre ☐	Training ☐	Crimp/Kink/Ripple/Wave ☐	Inspection Incomplete/Unqualified ☐	Wrong Stock Pulled ☐	Part Lost/Missing ☐	Material ☐	Use for Testing ☐	Cuffs ☐	Contamination ☐	Out of Sequence ☐	Part Moved ☐	Internal Transport ☐	Poor Information ☐	Crushing ☐	Countersink ☐	Off-set ☐	Drawing ☐	Tribal Knowledge ☐	Rushing ☐	Heat Treat ☐	Cut Too Short ☐	Mislabeled ☐	Finish ☐	LOA ☐	Product Improvement ☐	Wave/Twist in Tube ☐	Instructions Incomplete/Unclear ☐	Fit/Function ☐	Misread ☐	Substation ☐	Process Improvement ☐	Marks/Chatter ☐	Drill Holes ☐	Misaligned/off center ☐	Turning Sequence ☐	Past Expiry Date ☐	Manufacturing Process ☐	OTHER : _____			
Misidentified ☐	Past Due ☐																																																																

Work Order ID 137864

Tuesday, October 13, 2015 3:36:14 PM

137864

Page 2

Item ID: D350-689-021 Accept ***N900040100*** Setup Start ***NS1***
 Revision ID: Stop ***NS2***
 Item Name: Dual High-Back Seat Installation - Energy Attenuating Seat Compatible
 Start Date: 10/13/2015 Start Qty: 1.00 ***1*** Cust Item ID:
 Required Date: 10/29/2015 Req'd Qty: 1.00 ***1*** Customer:
 Reference:

Approvals: Process Plan: _____ Date: _____ Tooling: _____ Date: _____ Run Start ***NR1***
 QC: _____ Date: _____ SPC (Y/N): _____ Date: _____ Stop ***NR2***

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
130	Packaging	0.00					28 9-89		
130	Packaging	0.00				1X	28 9-89	DEC 10 2015	
Packaging	Memo								
Packaging	Identify and pack for shipping as per PPP D350-689-021								
	Location: _____								
	PPP Rev: _____								
140	QC21- Final Inspection - Work Order Release	0.00							
140	QC	0.00							
Quality Control	Memo								

DEC 1.1 2015

MF
15-12-10

DQA: _____ Date: _____



WORK ORDER NON-CONFORMANCE / UPDATE

QA Closed: _____ Date: _____

Work Order update only ☐

Work Order: _____ Part No. _____ NCR No. _____		DISPOSITION Rework ☐ Scrap ☐ Use-as-is ☐ Suspected Unapproved ☐		AGAINST DEPARTMENT/PROCESS Skid-tube ☐ Machining ☐ Thermoforming ☐ Large Fab ☐ Cross tube ☐ Small Fab ☐ Finishing ☐ Composite ☐ Water Jet ☐ Prod. Eng. Coord. ☐ Rec/Store/Packaging ☐ Supplier ☐ Engineering ☐ Quality ☐ Other ☐					
Date :		Step #:		QTY Effective :			MRB (QSI042) Approval Completed By Lead hand / Supervisor Approval Verification QC / QA Coordinator Approval		
Description Work Order Deviation				Disposition					
Root Cause Environment ☐ Design ☐ Doc/Data ☐ Equip/Tooling ☐ Handling/Pre ☐ Material ☐ Internal Transport ☐ Tribal Knowledge ☐ LOA ☐ Substation ☐ Past Expiry Date ☐ Misidentified ☐ No Re-verification ☐ Operator ☐ Offset/Setup ☐ Supplier ☐ Training ☐ Use for Testing ☐ Poor Information ☐ Rushing ☐ Product Improvement ☐ Process Improvement ☐ Manufacturing Process ☐ Past Due ☐		FAULT CATEGORY Pressure/Forced ☐ Bending ☐ Centre Not Concentric ☐ Cracks ☐ Crimp/Kink/Ripple/Wave ☐ Cuffs ☐ Crushing ☐ Heat Treat ☐ Wave/Twist in Tube ☐ Marks/Chatter ☐ Temperature/Cure ☐ Set-up ☐ BOM/Route ☐ Broken/Damage/Defect ☐ Inspection Incomplete/Unqualified ☐ Contamination ☐ Countersink ☐ Cut Too Short ☐ Instructions Incomplete/Unclear ☐ Drill Holes ☐		Power Loss/Surge ☐ Folio/Program ☐ Grain ☐ Weld ☐ Wrong Stock Pulled ☐ Out of Sequence ☐ Off-set ☐ Misabeled ☐ Fit/Function ☐ Misaligned/off center ☐ Positioned Wrong ☐ Outside Dimensions ☐ Over/Under tolerance ☐ Part Incorrect ☐ Part Lost/Missing ☐ Part Moved ☐ Drawing ☐ Finish ☐ Misread ☐ Turning Sequence ☐					
OTHER : ☐									

Picklist Print

Tuesday, October 13, 2015 3:36:14 PM

Page 1

Work Order ID: 137864

137864

Parent Item: D350-689-021

D350-689-021

Parent Item Name: Dual High-Back Seat Installation - Energy Attenuating Seat Compatible

Start Date: 10/13/2015

Required Date: 10/29/2015

Start Qty: 1.00

Required Qty: 1.00

Comments: IPP Rev:A 08-12-23 new issue DD verified by: LL 08.12.24 IPP
Rev:B chg002 DD 10.02.12 verified by:JLM IPP Rev:C
chg004 DD 11.09.28 verified by:JLM IPP Rev:D 12.01.12
now @ CHG005 (ecn12-501) DD VEF:EC

Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Qty per Kit	Total Qty	Qty Issued	Date Issued	Status
D350-689-023		Manufactured	No			110	Each	1.0000	1	1			BAS 27 9-89
D350-689-023									**	137751			
Floor Provisions Energy Attenuating Seat Compatible													
	DAS 28 9-89			<u>Location</u>				<u>Loc Qty</u>		<u>Loc Code</u>			
				FG027				1					
				134132				1					
D350-689-043		Manufactured	No			110	Each	0.0000	1	1			BAS 27 9-89
D350-689-043									**	139442			
Dual High Back Seat Assembly- Energy Attenuating Seat Compatible													
D3018-1		Manufactured	No			110	Each	8.0000	1	1			BAS 27 9-89
D3018-1									**				
Seat Cushion													
	DAS 28 9-89			<u>Location</u>				<u>Loc Qty</u>		<u>Loc Code</u>			
				Mezz2				8					
				132179				8					
D3019-1		Manufactured	No			110	Each	8.0000	1	1			BAS 27 9-89
D3019-1									**				
Back Cushion													
	DAS 28 9-89			<u>Location</u>				<u>Loc Qty</u>		<u>Loc Code</u>			
				Mezz2				8					
				132180				8					

DEC 09 2015

BAS 27 9-89

DQA: _____ Date: _____



WORK ORDER NON-CONFORMANCE / UPDATE

QA Closed: _____ Date: _____

Work Order update only ☐

Work Order: _____ Part No. _____ NCR No. _____		DISPOSITION Rework ☐ Scrap ☐ Use-as-is ☐ Suspected Unapproved ☐		AGAINST DEPARTMENT/PROCESS Skid-tube ☐ Machining ☐ Thermoforming ☐ Large Fab ☐ Cross tube ☐ Small Fab ☐ Finishing ☐ Composite ☐ Water Jet ☐ Prod. Eng. Coord. ☐ Rec/Store/Packaging ☐ Supplier ☐ Engineering ☐ Quality ☐ Other ☐							
Date :		Step #:		QTY Effective :			MRB (QSI042) Approval Completed By Lead hand / Supervisor Approval Verification QC / QA Coordinator Approval				
Description Work Order Deviation				Disposition							
Root Cause Environment ☐ Design ☐ Doc/Data ☐ Equip/Tooling ☐ Handling/Pre ☐ Material ☐ Internal Transport ☐ Tribal Knowledge ☐ LOA ☐ Substation ☐ Past Expiry Date ☐ Misidentified ☐		☐ No Re-verification ☐ Operator ☐ Offset/Setup ☐ Supplier ☐ Training ☐ Use for Testing ☐ Poor Information ☐ Rushing ☐ Product Improvement ☐ Process Improvement ☐ Manufacturing Process ☐ Past Due		☐ Pressure/Forced ☐ Bending ☐ Centre Not Concentric ☐ Cracks ☐ Crimp/Kink/Ripple/Wave ☐ Cuffs ☐ Crushing ☐ Heat Treat ☐ Wave/Twist in Tube ☐ Marks/Chatter		FAULT CATEGORY ☐ Temperature/Cure ☐ Set-up ☐ BOM/Route ☐ Broken/Damage/Defect ☐ Inspection Incomplete/Unqualified ☐ Contamination ☐ Countersink ☐ Cut Too Short ☐ Instructions Incomplete/Unclear ☐ Drill Holes		☐ Power Loss/Surge ☐ Folio/Program ☐ Grain ☐ Weld ☐ Wrong Stock Pulled ☐ Out of Sequence ☐ Off-set ☐ Mislabeled ☐ Fit/Function ☐ Misaligned/off center		☐ Positioned Wrong ☐ Outside Dimensions ☐ Over/Under tolerance ☐ Part Incorrect ☐ Part Lost/Missing ☐ Part Moved ☐ Drawing ☐ Finish ☐ Misread ☐ Turning Sequence	
OTHER : _____											

5.0 PARTS LIST

DAS
28
9-89DAS
28
9-89

Qty -011	Qty -013	Qty -021	Qty -023	Qty -041	Qty -043	Part Number	Description
X						D350-689-011	DUAL HIGH BACK SEAT INSTALLATION, LH
1	X					D350-689-013	FLOOR PROVISIONS KIT
		X				D350-689-021	DUAL HIGH BACK SEAT INSTALLATION, LH
		1	X			D350-689-023	ENERGY ATTENUATING FLOOR PROVISIONS KIT
1				X		D350-689-041	DUAL HIGH BACK SEAT ASSEMBLY
		1			X	D350-689-043	DUAL HIGH BACK SEAT ASSEMBLY
1		1				D3018-1	SEAT CUSHION
1		1				D3019-1	BACK CUSHION
	1					D3025-1	BEAM
	1					D3027-1	CLIP
	1					D3027-3	CLIP
	1					D3027-5	CLIP
	4		4			D3027-7	CLIP
				4		D3028-1	STUD
				2		D3029-1	SPRING
				2		D3030-1	LOCK
	1					D3032-1	SPACER
	2					D3033-1	SEAT TRACK
	1					D3234-1	DOUBLER
	2					D3234-5	SPACER
					2	D3808-041	SEAT RAIL ASSEMBLY
					4	D3809-1	SLIDING BLOCK
			1			D3811-041	SEAT TRACK ASSEMBLY
	1		1			D4575-1	BEAM
	1		1			D4575-3	DOUBLER
				1	1	D5162-041	SEAT STRUCTURE ASSEMBLY
			9			MS21042L3	NUT (OR MS21042-3)
	12					MS21059L3	NUTPLATE
	2					MS24693-S273	SCREW
			9			MS24694-S50	SCREW
	6					MS27039-1-10	SCREW
	6					NAS1149D0332J	WASHER (OR AN960JD10L)
			9			NAS1149D0363J	WASHER (OR AN960JD10)

• COPYRIGHT © 2011 BY DART AEROSPACE LTD •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: C
Date: 14.12.01

Tuesday, October 13, 2015 3:36:14 PM

137864

Page 1

N900040100

Setup Start *NS1*

Stop *NS2*

Start Date: 10/13/2015 **Start Qty:** 1.00 ***1***

Cust Item ID:

Required Date: 10/29/2015 **Req'd Qty:** 1.00 *** 1 ***

Customer:

Reference:

Approvals: Process Plan: mc Date: 15-10-13 Tooling: Date:

Run Start *NR1*

QC: _____ Date: _____ SPC (Y/N): _____ Date: _____

Stop *NR2*

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
--------------------------------	--------------------------	----------------------	---------	--------	--------------	---------------	---------------	------------------	----------------

Draw Nbr	Revision Nbr	
IIN-D350-689	C	

100

Document Control

0.00

100

DOCUMENT CONTROL

DC

Memo

0.00

Doc.Control -USB or Paperwork

Photocopy bluefile and create labels per PPP D350-689-021 CHG006

110

Pick Kit

0.00

110

Packaging

Memo

0.00

Packaging

120

QC4- 100% Inspect kits for completeness

0.00

120

QC

Memo

0.00

Quality Control